

LG GDK TIME CHANGE

1. From the main extension (normally ext 100),
2. Press the "Trans/pgm" key.
3. Dial #1*
4. Dial the new 24hr time
5. Then press the "Hold/save" key

LG LDK & NEXER TIME CHANGE

1. From the main extension (normally ext 100 or 10),
2. Press the "Trans/pgm" Key
3. Dial 041,
4. Press the "Hold/Save" key
5. Dial the 24hr time
6. Then press the "Hold/save" key again